

Dispenser for Mixing Cups



Диспенсер для мерных ёмкостей

Installation manual

1. Take out the dispensers from the box and remove the packaging film. Take one dispenser out of the other.
2. Lay out and mark the points for fixing holes on the vertical surface to hang the dispenser at certain height convenient for the everyday work. Carefully drill the holes.
3. Insert the dowels from the kit into the drilled holes. Twist the screws in the dowels leaving a few millimeters gap between the heads of the screws and the surface to hang the dispenser.
4. Hang the dispenser.
5. Slightly bend the tongues at the lower part of the dispenser inwards in a way that they hold the cups placed in the dispenser, see Fig. 1.

Инструкция по монтажу

1. Достать диспенсеры из коробки, снять упаковочную пленку, достать один диспенсер из другого.
2. Разметить точки для крепежных отверстий на вертикальной поверхности для установки диспенсера на высоте, удобной для повседневной работы. Аккуратно просверлить отверстия.
3. Вставить в просверленные отверстия дюбели из комплекта, ввинтить в них шурупы, оставив зазор в несколько миллиметров между поверхностью и головками шурупов для навешивания диспенсера.
4. Навесить диспенсер.
5. Слегка согнуть «язычки» в нижней части диспенсера внутрь так, чтобы они удерживали находящиеся в диспенсере емкости, см. рис. 1.



Bottom view | Вид снизу

Fig. 1 | Рис. 1